




# Montageanleitung Montážny návod


## POINT Plus

Type/Typ **53,83**  
MN 144/53









<b>1</b>		ø15 x8
<b>2</b>		ø8 x8
<b>3</b>		ø10x40 x16
<b>4</b>		x16
<b>5</b>		x14
<b>6</b>		ø4x50 x16
<b>7</b>		x4
<b>8</b>		x4
<b>9</b>	 A	x8
	 B	x4


### SERVISKARTE / SERVISNÁ KARTA




# 1





2



3





zudrehen / zatiahnut




(5)




(5)



RECTIFICATION




(9)A




(4)

(9)A




D

D





(8)



P1 S 5X / POINT S 5X / POINT PLUS S 5X

P1 S 8X / POINT S 8X / POINT PLUS S 8X



	OBERSCHUBKASTEN	AA O 	x2 N	x4	X	S 5X-x4 S 8X-6x
	UNTERSCHUBKASTEN				Ø6.3x11 x8 P ØM4x10 x4 KE x4 AC M4x25 x4 F x1 Y	S 5X-x4 S 8X-6x

