












CABANA 07





1 ø8x35 x14	2 ø15 x10	3 ø8 x10	4 ø15 x3	5 ø7x50 x6
6 ø35 x2	7 ø5x25 x1	8 x4	9 ø1,2x25 x8	10 x4
11 ø6,3x11 x4	12 x2	13 x2	14 x1 290	15 M4x23 x4





2.




3.







4.



5.




6.



7.

Höheneinstellung / výškové nastavenie



$\pm 4 \text{ mm}$

