




SK NÁVOD NA MONTÁŽ
CZ MONTÁŽNÍ NÁVOD
HU SZERELÉSI UTASÍTÁS
DE MONTAGEANLEITUNG

CASSA NEW

	1860	mm
	1081	
	2110	





ID	
2	1x
3	2x
4	1x
5	2x
6	2x
7	10x
8	4x
9	1x
10	1x
11	1x
12	1x










A 100x	B 12x	C 32x	D 32x	E 38x	F 38x	G 22x	H 40 x	J 2x	K 2x



L 12x	M 12x	N 4x











						
A 6x	B 3x	E 12x	F 12x	G 4x	H 4x	J 2x




		
D 20x	C 8x	G 4x




			
C 12x	H 6x	E 8x	F 8x



		
L 12x	M 12x	N 4x





Ø3,5*16

H 24x

