





P1 S 5X / POINT S 5X / POINT PLUS S 5X

P1 S 8X / POINT S 8X / POINT PLUS S 8X



	OBERSCHUBKASTEN	AA	x2 N	x4	X S 5X-x4 S 8X-6x
	UNTERSCHUBKASTEN				








Montageanleitung Montážny návod

POINT Plus



Type/Typ **50,80**

MN 144/50









1		ø15 x8
2		ø8 x8
3		ø10x40 x16
4		x4
5		x8
6		ø4x35 x16
7		x4
8		x2
9		A x8 B x4

SERVISKARTE / SERVISNÁ KARTA










1



2

zudrehe / zatiahnúť



3

