



	AA		x1	NA		x2		SUT 5XN-x4 SUT 5XH-x4 SUT 8XN-6x SUT 8XH-x6	Y		ø3,5x20 SUT 5XN-x4 SUT 5XH-x4 SUT 8XN-6x SUT 8XH-x6			
	O		ø6.3x11 x6	P		øM4x10 x2	KE		x2	AC		M4x25 x2	F	







Montageanleitung Montážny návod


POINT Plus

Type/Typ **UT 5/UT 8**

MN 144/5




Typ UT5




Typ UT8

1		ø15 x12
2		ø8 x12
3		ø10x45 x20
4		x6
5		x6
6		ø4x35 x16
7		x4
8		x3
9		A x8 B x4

SERVISKARTE / SERVISNÁ KARTA










Typ UT5









Typ UT8

1





2

zudrehen / zatiahnúť



3



RECTIFICATION

